

1998 to Current



Venture

September 25, 2002

2097

2121


	Installation Guide	Chevy Venture Van / Pontiac Montana	Product No.
--	--------------------	-------------------------------------	-------------

Extended Wheelbase


				and the second second			Montana 2121
		Oty.	<b>Description</b>		Qty.		Description
	Α	1	GlaStep (Driver Side)		G	6	Angled Straps #AS01
Installation	В	1	GlaStep (Passenger Side)		H	24	5/16" x 3/4" Washer Head Bolts
Parts List:	C	4	Step Pads		I	24	5/16" Washer Head Nuts
	D	2	Foam Tape Strips		J	18	#14 x 3/4" Self-Drilling Screws
	E	6	Flat Plates #FL44		K	6	#12 x 1-1/4" Self-Drilling Screws
	F	6	Step Supports #3124F				With Rubber Washers

Tools Required:	5/16" Drill	•	1/2" Hex Socket	•	1/2" Wrench	•	5/16" Nut Driver	•	3/8" Nut Driver


- 1. Prior to painting, fit your GlaSteps to the body. A good fit is accomplished when mating surfaces fit with minimum light gaps. Note: Vehicle bodies have variations and a perfect fit may not be possible.
- 2. Painting your GlaSteps. To insure a proper paint finish, use a top quality auto paint system and follow the manufacturers instructions. Your GlaSteps should be sanded and primed before painting.




3. Measure from front wheel well, back 20", 34" and 60". Mark these bracket locations. Note: Steel plates have been inserted under fiberglass to mount brackets securely using self-drilling screws. Double check your marks to be sure they line up with the steel plates before drilling.




4. Assemble bracket components with 5/16" nuts & bolts as shown. Do not tighten at this time.




5. Drill 5/16" hole in pinch weld so that AS01 on bracket assembly mates at pinch weld. Secure with 5/16" nut and bolt, then install #14 x 3/4" self-drilling screw at top of FL44.




Apply foam tape to top edge of GlaStep. Remove protective strip from top edge of foam tape.



 Position step on brackets and tight to truck body. Screw step to truck with #12 x 1-1/4" self-drilling screws with rubber washers (K), three per side.



 Screw step to bracket using two #14 x 3/4" self-drilling screws per bracket.
Tighten all bolts to 18 foot pounds.



9. Place pad on step. Peel off tape backing to secure. Don't forget the Owens label!

IN-111 9/25/02