

P.O. Box 670
1107 Progress Street
Sturgis, MI 49091 USA

Toll Free: 800-726-9367
Phone: 269-651-2300
Fax: 269-651-9326

Website: www.OwensProducts.com
Email: Sales@OwensProducts.com

Rear Van Steps – Available Now!!



These are **NO DRILL** into the vehicle.

Call and order yours today!

Part Number	Description
82340	11-15 NV Full Size Van - Rear Step (Dia. Plt. w/ Starburst Grip)
82341	11-15 NV Full Size Van - Rear Step (Grip Strut)
82342	2014 Ram Promaster - Rear Step w/ No Drill Brackets
82343	2015 Ford Transit - Rear Step w/ No Drill Brackets