



P.O. Box 670
1107 Progress Street
Sturgis, MI 49091 USA

Toll Free: 800-726-9367
Phone: 269-651-2300
Fax: 269-651-9326

Website: www.OwensProducts.com
Email: Sales@OwensProducts.com

Wide Step TPO for Ford Transit!!



Available as Long passenger/Short driver. The brackets are **NO DRILL** into the vehicle.

<u>P/N</u>	<u>Description</u>
6834114W-01	15+ Ford Transit short driver/long wide step passenger boards only - Must order bracket kit separately.
10-1288	Bracket kit for 6834114W-01 (350 with Dual Rear Wheel)

More applications coming soon!