

Ford E-Series Van Cheat Sheet

TYPE	DROP	DESCRIPTION	LENGTH	PART NUMBERS	REQUIRED BRACKET KIT
92-14 Ford E-Series Van 138" Wheel Base					
Long/Long	4"	ClassicPro Aluminum	102"	OC74102X OC74102XB OC84102X	Included
		Classic Extra-Wide Diamond Universal	102"	OC84102-8 OC84102-10	Included
		Commercial Extra-Wide Universal	102"	OC84102LA-8 OC84102LA-10	Included
		Owens Commercial Boards	102"	82013 82013G	Included
	2"	GlaStep Molded Fiberglass	102"	2190	Included
		Owens Factory Molded TPO	100"	68100-01	10-1129
		ClassicPro Aluminum	102"	OC70102X OC70102XB OC80102X	Included
		Classic Extra-Wide Diamond Universal	102"	OC80102-8 OC80102-10	Included
		Commercial Extra-Wide Universal	102"	OC80102-8-100 OC80102-10-100	Included
		Fusion Oval Steps	100"	OC5196B-01 OC5196N-01	10-1129
TranSender Extruded Aluminum	100"	76100-01	10-1129		
Short/Long	4"	ClassicPro Aluminum	40"/102"	OC72404 OC72404B OC82404	Included
		Owens Commercial Boards	40"/102"	82014 82014G	Included
	2"	Owens Factory Molded TPO	40"/100"	6840100-01	10-1130
		Classic Extra-Wide Diamond Universal	40"/102"	OC82404-8	Included
		Fusion Oval Steps	40"/100"	OC513796B-01 OC513796N-01	10-1130
		TranSender Extruded Aluminum	40"/100"	7640100-01	10-1130
92-19 Ford E-Series Cutaway Van 138" Wheel Base					
Short/Short	4"	ClassicPro Aluminum	40"	OC7440CX OC7440CXB OC8440CX	Included
		Classic Extra-Wide Diamond Universal	40"	OC8440C-8 OC8440C-10	Included
		Commercial Extra-Wide Universal	40"	13133	Included
		Owens Commercial Boards	40"	82028 82028G	Included
	2"	Owens Factory Molded TPO	40"	6840-01	10-1101
		TranSender Molded TPO	40"	6540-01	10-1101
		ClassicPro Aluminum	40"	OC7040CX OC7040CXB OC8040CX	Included
		Classic Extra-Wide Diamond Universal	40"	OC8040C-10	Included
		Fusion Oval Steps	40"	79001 78001	Included
		TranSender Extruded Aluminum	40"	7640-01	10-1101

Visit our website
for product
details on any
part number.

68100-01

-01

Part Numbers ending with
"-01" means a bracket kit
must be ordered separately.