

TYPE	DROP	DESCRIPTION	LENGTH	PART NUMBERS	REQUIRED BRACKET KIT
07-19 Dodge/Freightliner/Mercedes-Benz Sprinter 144" Wheel Base					
Long/Long	4"	ClassicPro Aluminum	105.5"	OC74105EX-01 OC74105EXB-01 OC84105EX-01	10-1269
		Owens Commercial Boards	105.5"	82327-01 82327G-01	10-1269
Short/Long	4"	ClassicPro Aluminum	34"/105.5"	OC72401-01 OC72401B-01 OC82401-01	10-1270
		Owens Commercial Boards	34"/105.5"	82325-01 82325G-01	10-1270
	2"	Owens Factory Molded TPO Wide Step	34"/103"	68010 (Years 10-19 only)	Included
Short/Short	4"	ClassicPro Aluminum	34"	OC7434X-01 OC7434XB-01 OC8434X-01	10-1273
		Commercial Extra-Wide Universal	34"	OC8434-10-100	Included
		Owens Commercial Boards	34"	82339 82339G	Included
07-19 Dodge/Freightliner/Mercedes-Benz Sprinter 170" Wheel Base					
Long/Long	4"	ClassicPro Aluminum	131.5"	OC74131EX-01 OC74131EXB-01	10-1271
Short/Long	4"	ClassicPro Aluminum	34"/131.5"	OC72403-01 OC72403B-01	10-1272
	2"	Owens Factory Molded TPO Wide Step	34"/124"	6834124W-01 (Years 10-19 only)	10-1295
		Grip Strut Commercial	34"/124"	823661379	Included
Short/Short	4"	ClassicPro Aluminum	34"	OC7434X-01 OC7434XB-01 OC8434X-01	10-1273
		Commercial Extra-Wide Universal	34"	OC8434-10-100	Included
		Owens Commercial Boards	34"	82339 82339G	Included



Visit our website
for product
details on any
part number.

68010
WIDE STEP

-01

Part Numbers ending with
"-01" means a bracket kit
must be ordered separately.