

TYPE	DROP	DESCRIPTION	LENGTH	PART NUMBERS	REQUIRED BRACKET KIT
10-13 Ford Transit Connect					
Long/Long	2"	TranSender/Factory Molded TPO	80"	6580-01 6880-01	10-1103
15-19 Ford Transit 150 250 130" Wheel Base					
Long/Long	4"	Owens Factory Molded TPO	94"	6894-01	10-1365
		ClassicPro Aluminum	84"	74007 75007 84007	Included
	2"	Grip Strut Commercial	90"	82362-01	10-1362
Short/Long	4"	Owens Factory Molded TPO	34"/94"	683494-01	10-1366
		ClassicPro Aluminum	32"/84"	72001 73001 81001	Included
	2"	Owens Factory Molded TPO Wide Step	34"/94"	68016	Included
		Grip Strut Commercial	34"/90"	82363	Included
Short/Short	4"	Owens Factory Molded TPO	34"	6834-01	10-1367
		ClassicPro Aluminum	32"	OC7432X-01 OC7432XB-01 OC8432X-01	10-1367
Rear Step	4"	Grip Strut Commercial	65"	82343	Included
15-19 Ford Transit 150 250 148" Wheel Base					
Long/Long	4"	Owens Factory Molded TPO Single Slider	114"	68114-01	10-1230
		Owens Factory Molded TPO Dual Slider	114"	68114-01	10-1351
		ClassicPro Aluminum Single Slider	114.5"	OC74114E-01 OC74114EB-01 OC84114E-01	10-1230
		ClassicPro Aluminum Dual Slider	114.5"	OC74114E-01 OC74114EB-01 OC84114E-01	10-1351
		Owens Commercial Boards Single Slider	114.5"	OC84114E-01-100	10-1230
		Owens Commercial Boards Dual Slider	114.5"	OC84114E-01-100	10-1351
	2"	ClassicPro Aluminum Single Slider	114.5"	OC70114E-01 OC70114EB-01	10-1308
		Owens Commercial Boards Single Slider	114.5"	OC80114E-01-100	10-1308
		Grip Strut Commercial Single Slider	114.5"	82360-01	10-1358
Short/Long	4"	Owens Factory Molded TPO	34"/114"	6834114-01	10-1359
		ClassicPro Aluminum	32"/114.5"	OC72408-01 OC72408B-01 OC82408-01	10-1359
		Fusion Oval Steps	34"/114"	OC5131111B-01 OC5131111N-01	10-1359
	2"	Owens Factory Molded TPO Wide Step	34"/114"	6834114W-01	10-1354
		ClassicPro Aluminum	32"/114.5"	OC72411-01 OC72411B-01	10-1268
		Fusion Oval Steps	34"/114"	OC5131111B-01 OC5131111N-01	10-1268
		Owens Commercial Boards	32"/114.5"	OC82411-01-100	10-1268
Grip Strut Commercial	34"/114.5"	82361-01	10-1357		
Short/Short	4"	Owens Factory Molded TPO	34"	6834-01	10-1367
		ClassicPro Aluminum	32"	OC7432X-01 OC7432XB-01 OC8432X-01	10-1367
Rear Step	4"	Grip Strut Commercial	65"	82343	Included

Visit our website
for product
details on any
part number.

6834114W-01
WIDE STEP

TYPE	DROP	DESCRIPTION	LENGTH	PART NUMBERS	REQUIRED BRACKET KIT
15-19 Ford Transit 350 148" Wheel Base - Single Rear Wheel					
Long/Long	4"	Owens Factory Molded TPO Single Slider	114"	68114-01	10-1283
		Owens Factory Molded TPO Dual Slider	114"	68114-01	10-1351
		ClassicPro Aluminum Single Slider	114.5"	OC74114E-01 OC74114EB-01 OC84114E-01	10-1283
		ClassicPro Aluminum Dual Slider	114.5"	OC74114E-01 OC74114EB-01 OC84114E-01	10-1351
		Owens Commercial Boards Single Slider	114.5"	OC84114E-01-100	10-1283
		Owens Commercial Boards Dual Slider	114.5"	OC84114E-01-100	10-1351
	2"	ClassicPro Aluminum Single Slider	114.5"	OC70114E-01 OC70114EB-01	10-1308
		Owens Commercial Boards Single Slider	114.5"	OC80114E-01-100	10-1308
		Grip Strut Commercial Single Slider	114.5"	82360-01	10-1358
Short/Long	4"	Owens Factory Molded TPO	34"/114"	6834114-01	10-1359
		ClassicPro Aluminum	32"/114.5"	OC72408-01 OC72408B-01 OC82408-01	10-1359
		Fusion Oval Steps	34"/114"	OC5131111B-01 OC5131111N-01	10-1359
	2"	Owens Factory Molded TPO Wide Step	34"/114"	6834114W-01	10-1354
		Grip Strut Commercial	34"/114.5"	82361-01	10-1357
		Short/Short	4"	Owens Factory Molded TPO	34"
ClassicPro Aluminum	32"	OC7432X-01 OC7432XB-01 OC8432X-01	10-1367		
Rear Step	4"	Grip Strut Commercial	65"	82343	Included
15-19 Ford Transit 350 148" Wheel Base - Dual Rear Wheel (Dually)					
Long/Long	4"	Owens Factory Molded TPO Single Slider	114"	68114-01	10-1285
		ClassicPro Aluminum Single Slider	114.5"	OC74114E-01 OC74114EB-01 OC84114E-01	10-1285
		Owens Commercial Boards Single Slider	114.5"	OC84114E-01-100	10-1285
	2"	ClassicPro Aluminum Single Slider	114.5"	OC70114E-01 OC70114EB-01	10-1308
		Owens Commercial Boards Single Slider	114.5"	OC80114E-01-100	10-1308
		Grip Strut Commercial Single Slider	114.5"	82360-01	10-1358
Short/Long	4"	Owens Factory Molded TPO	34"/114"	6834114-01	10-1359
		ClassicPro Aluminum	32"/114.5"	OC72408-01 OC72408B-01 OC82408-01	10-1359
		Fusion Oval Steps	34"/114"	OC5131111B-01 OC5131111N-01	10-1359
	2"	Owens Factory Molded TPO Wide Step	34"/114"	6834114W-01	10-1354
		Grip Strut Commercial	34"/114.5"	82361-01	10-1357
		Short/Short	4"	Owens Factory Molded TPO	34"
ClassicPro Aluminum	32"	OC7432X-01 OC7432XB-01 OC8432X-01	10-1367		
Rear Step	4"	Grip Strut Commercial	65"	82343	Included



OC74114EB-01

-01

Part Numbers ending with
"-01" means a bracket kit
must be ordered separately.